

New for 2011/2012!



Welcome to the new e Series FootWarmers for 2011/2012

FootWarmer

e **4** POWER PLUS

e **3** POWER PLUS

HOW FEET BECOME COLD

When colder outside temperatures are detected, the nervous system restricts blood flow to the extremities to maintain the body's core temperatures. The toes (and other extremities) quickly become uncomfortably cold.



HOTRONIC KEEPS FEET WARM

By providing a base level temperature at the toes, Hotronic's Heating Element blocks and neutralizes the penetrating cold keeping the blood circulation open and maintaining comfort and warmth in the feet.



The Hotronic FootWarmer offers three base level settings for comfort and warmth maintenance. A fourth setting offers an extra blast of heat when needed.

WHEREVER YOU GO

Hotronic's FootWarmers easily install in all types of footwear and transfer simply from one pair to another. Use while skiing, snowboarding, snowshoeing, bicycling, horseback riding, fishing, and during other general cold-temperature activities.



NEW e SERIES FOOTWARMER

Hotronic's new e Series FootWarmer offers more heat at each of the three base level settings for added comfort and warmth. Plus, the new e Series batteries maintain up to 70% of their charge after twelve (12) months of non-use *and* provide power when needed most, in the cold!



TWO MODELS TO CHOOSE FROM

With four (4) batteries in each Battery Pack, the FootWarmer Power Plus e4 is Hotronic's longest lasting, most powerful FootWarmer. For compact power, the FootWarmer Power Plus e3 comes with three (3) batteries in each Battery Pack. Hotronic's e Series Recharger and Heating Elements come standard with each model.



Keeping Feet Warmer - LONGER

New for 2011/2012!



Welcome to the new e Series FootWarmers for 2011/2012


FootWarmer

e4 POWER PLUS

e3 POWER PLUS

READY FOR THE COLD

Hotronic's new e Series FootWarmers, designed for cold-temperature operation, maintain up to 70% of their charge after twelve (12) months of non-use! That's power when needed most! NiMH batteries do NOT have a "memory effect" and do NOT require fully discharging before fully recharging.



A SMARTER WAY TO RECHARGE

Wherever one goes worldwide, Hotronic's advanced global charging technology senses when the batteries are charged and protects them from overcharging damage by switching to trickle current recharging. Compatible with both the e Series and m Series Battery Packs, the Recharger's LEDs indicate recharging mode and battery charge status.



SET FOR COMFORT & WARMTH

The Hotronic FootWarmer offers three base level settings for comfort and warmth maintenance. A fourth setting offers an extra blast of heat when needed. Press-and-release the Battery Pack's ON or OFF button to select each setting. Easy to read LED lights indicate the setting selected and when the power is on or off.

Temperature & Duration Chart			
Setting	Approximate Average Temp. °F	Duration Range	
		e4 POWER PLUS	e3 POWER PLUS
1	84 - 95	16.5 - 19.5 hrs	14.5 - 17.75 hrs
2	107 - 118	7 - 9.25 hrs	5.5 - 7 hrs
3	122 - 132	5 - 6.5 hrs	3.5 - 5.5 hrs
4	158 - 168	2.5 - 4 hrs	2 - 3.5 hrs

Based on Battery Pack in ambient temperatures of -22° to -15°C (-9° to +4°F).
Based on Heating Element in ambient temperatures of 20° to 26°C (68° to 79°F).

AN ELEMENT OF HEAT

By blocking and neutralizing the penetrating cold, Hotronic's Heating Element keeps the blood circulation open while maintaining comfort and warmth in the feet. The Heating Element's large oval shape and self-adhesive backing provides effective anatomical coverage of the toes and easily installs in Hotronic's Heat Ready Insoles or on insoles of one's own choice.



Keeping Feet Warmer - LONGER